




Star and MiniStar Pillars

Installation

Components	Assembly	Completed Set Up
		
<p>Included are:</p> <ul style="list-style-type: none"> • 2 vertical sides • Round base • Round top ring • Cylinder top • 1 can gel fuel 	<p>To assemble:</p> <ol style="list-style-type: none"> 1. Slide side with bottom slit over top slit side 2. Lay sides down, and place base at the bottom 3. Turn round base so grooves are between sides and stand unit up 4. Place cylinder and ring on top 5. Insert gel fuel can inside cylinder 	<p>To install:</p> <p>Place pillar in desired position. May be secured through the center hole in the base with a lag bolt (if necessary).</p>

Use and Care

<p>Directions for use:</p> <ul style="list-style-type: none"> • Shake can well before using. Use extreme caution and place hand over lid pointed away from face while opening (32 oz. can). • Each can burns 2-3 hours with a beautiful 4-7" vibrant yellow flame and a wonderful crackling sound effect • Only re-use cans for 3-4 fires, then replace with fresh new clean quart cans (found in hardware stores) 	<p>To refill:</p> <ol style="list-style-type: none"> 1. Store refill bottle in cool, dark area 2. READ ALL DIRECTIONS before refilling 3. Shake refill bottle before using 4. Pour with caution - if spilled, clean with water and do not light near spillage 5. Replace child lock safety cap each time bottle is opened
<p>Corten Steel – a.k.a. weathering steel, a special alloy that uses copper and nickel to create a weather-resistant surface. Can be left untreated and is maintenance free.</p>	<p>Gel fuel - alcohol based, with water, salt and thickening agents, lasts for 2 years, NOT explosive</p>